

FUSES & CIRCUIT BREAKERS

Article Text

1994 Suzuki Swift

For Xeon

Copyright © 1998 Mitchell Repair Information Company, LLC
Tuesday, December 02, 2003 06:31PM

ARTICLE BEGINNING

Fuses & Circuit Breakers
1989-94 Suzuki


Swift

FUSES & CIRCUIT BREAKERS

FUSE PANEL LOCATION

Fuse panel is located under the instrument panel above the driver's left knee. Main service fuses, which supply the fuse panel, are located in the engine compartment, near the battery.

UNDERHOOD MAIN FUSE PANEL IDENTIFICATION



PRIMARY FUSES/FUSIBLE LINKS


93A45476

Fig. 1: Underhood Main Fuse Panel Identification
Courtesy of Suzuki of America Corp.

WARNING: Always disconnect battery ground cable before servicing "high-current fuses. It is recommended that "high-current" fuses be replaced by a qualified technician.

- A - (Yellow)
Main Fuse Supply
- B - (Green)
Primary Fuse
- C - (Pink)
Primary Fuse
- D - (Pink)
A/C Primary Fuse
- E - (Blue)
Electronic Fuel Injection
- F - (Blue)
A/C Circuit Fuse

UNDERDASH FUSE PANEL IDENTIFICATION



93B45477

Fig. 2: Underdash Fuse Panel Identification
Courtesy of Suzuki of America Corp.

Fuse & Circuit Breaker Identification

- 1 - 10 Amp
Left Side Headlight & High Beam Indicator
- 2 - 10 Amp
Right Side Headlight
- 3 - 15 Amp
Dome Light, License Plate Light, Front & Rear Marker Light,
Instrument Panel Illumination
- 4 - 15 Amp
Front Foglight
- 5 - 15 Amp
Hazard Warning Circuit & Horn
- 6 - 20 Amp
Ignition System & Gauges, Warning Lights
- 7 - 20 Amp
Heater Fan Motor, A/C Circuit
- 8 - 15 Amp
Stoplights
- 9 - 15 Amp
Cigarette Lighter & Radio
- 10 - 10 Amp
Back-Up Light
- 11 - 15 Amp
Rear Defogger
- 12 - 15 Amp
Front & Rear Wiper/Washer
- 13 - Relay
Switch
- 14 - Relay
Turn Signal

END OF ARTICLE